

Changing the Battery in your Key Fob



Our Key Fobs use radio frequencies to activate the door panels. Therefore, if your Key Fob opens the doors but not the garage door, then your Fob is having a battery issue. In the event that the batteries in your Key Fob need to be replaced, you may do so by following these instructions:



Our Key Fobs use a 2032 battery, as seen here. They are available at many stores, including local drug stores, for under \$2. Management does not supply or sell Key Fob batteries.

To open your Key Fob, locate the notch on the right side of the Fob. Insert a coin into the slot and twist until the 2 pieces separate, then carefully pull the pieces apart with your fingers.



Locate the battery in the center of the Key Fob board, pull out and replace. Place batteries positive side up.

The average life span of a Key Fob used regularly is ~3 years. Replacement Key Fobs are available in the Management Office: \$75 each (check or money order only). Key Fobs are for purchase only; they are non-refundable and do not carry a warranty.



If you find that there is blue and/or green corrosion inside of your Key Fob, then your Key Fob has been exposed to water. In the case of water damage, it is likely that replacing the battery will not solve the problem. You will need to replace a water damaged Key Fob.